

Manual, Assembly instruction: Brodit 855610

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed "Gap Opener" in the gap between the center console and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.

2. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.