

Manual, Assembly instruction: Brodit 855612

Center mount, Low

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder + equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the padded console and the hard plastic console panels, to widen the gap. Press the top edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).

2. Locate a seam under the center console and press the Gap Opener (Spaltöffner) into the seam.

3. Press the ProClip downward to insert the lower edge into the gap next to the Gap Opener (Spaltöffner). Press the ProClip all the way into the gap. Pull out the Gap Opener (Spaltöffner).

4. The ProClip is in place.