

Manual, Assembly instruction: Brodit 855613

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin edge on the upper part of the ProClip into the gap between the console frame and the display.

2. Press down on the left side of the ProClip. Press the ProClip to the right and hook the lower edge into the gap under the console frame.

3. The ProClip is in place.

4. The ProClip is in place.