

Manual, Assembly instruction: Brodit 855614

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin top edge of the ProClip into the gap between the air vent and the surrounding frame.

2. Hook the notched lower edge over the frame surrounding the air vent.

3. This ProClip can also be placed onto the right air vent.

4. The ProClip is in place.