

Manual, Assembly instruction: Brodit 855615

Center mount NOT for large devices.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard. Press the thin right edge of the ProClip into the gap next to the gap opener.

2. Press forward on the left side of the ProClip so the left edge of the ProClip goes into the gap between the panel and the surrounding frame. Pull out the gap opener.

3. NOTICE: NOT recommended for installation of a larger device due to the device hitting the wiper lever.

4. The ProClip is in place.