

Manual, Assembly instruction: Brodit 855616

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end on the upper part of the ProClip into the gap behind the frame surrounding the air vent. The ProClip should be placed close to the center vent control panel.

2. Press the ProClip upward/forward and hook the grooved lower edge over the lower edge of the air vent.

3. This ProClip can be placed on the right air vent.

4. The ProClip is in place.