

Manual, Assembly instruction: Brodit 855618

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the left edge of the ProClip onto the left edge of the air vent frame.

2. Press the ProClip to the right and hook the right edge of the ProClip onto the right edge of the air left vent frame.

3. The right seam can be difficult to get the mount into but it is very important to do or the mount will not be secure on the right side. To help, try placing the gap opener into the seam under the dash panel and gently pressing forward to lift the panel a little. This will open the seam to allow the mount edge to go in. When the right edge of the mount is in the seam, the mount should not move forward and back in the vent opening and the tape should connect.

4. The ProClip is in place.