

Manual, Assembly instruction: Brodit 855619

Center mount ONLY for automatic transmission.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Hook the angled edge on the upper part of the ProClip over the frame surrounding the air vent.

2. Press forward on the lower part of the ProClip and hook the angled edge into the gap next to the gap opener. Press upward on the lower part so the edge goes all the way into the gap. Pull out the gap opener.

3. This ProClip can also be placed on the right air vent.

4. The ProClip is in place.