

Manual, Assembly instruction: Brodit 855621

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the grooved lower edge of the ProClip over the frame surrounding the air vent.

2. Press the upper part of the ProClip forward so the grooved edge hooks under the frame surrounding the air vent.

3. The ProClip mount is in place.

4. The ProClip mount is in place.