

Manual, Assembly instruction: Brodit 855625

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin edge on the upper part of the ProClip under the frame surrounding the air vent.
2. Press the ProClip downward/forward. Hook the angled lower edge over the trim.
3. This ProClip can be placed onto the right air vent.
4. The ProClip is in place.