

Manual, Assembly instruction: Brodit 855629

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder + equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between padded dashboard top and the plastic frame around the speedometer, to widen the gap. Peel off the adhesive tape cover on the ProClip. Hook the left edge of the ProClip into the gap between the clear plastic and the frame around the speedometer.

2. Press in on the forward edge of the ProClip to make sure it stays hooked onto the panel while you rotate the mount rightwards. Pull the mount towards you and hook the right edge of the ProClip into the gap next to the Gap Opener (Spaltöffner).

3. Press hard on the ProClip so the right edge goes properly in place. Pull out the Gap Opener (Spaltöffner).

4. The ProClip is in place.