

Manual, Assembly instruction: Brodit 855632

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the upper grooved edge under the frame surrounding the air vent.

2. Hook the lower edge of the ProClip over the frame surrounding the air vent.

3. This ProClip can be installed in any position within the width of the air vents.

4. The ProClip is in place.