

Manual, Assembly instruction: Brodit 855634

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the notched left edge of the ProClip onto the air vent frame so the adhesive tape attaches.

2. Press the right part of the ProClip leftward/forward. Hook the notched right edge onto the air vent frame.

3. The ProClip mount is in place.

4. The ProClip mount is in place.