

Manual, Assembly instruction: Brodit 855645

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the upper part of the ProClip by the gap between the frame surrounding the air vent and the dashboard.

2. Press the ProClip forward so the lower edge hooks onto the frame surrounding the air vent, at the same time as the angled upper edge goes into the gap between the frame surrounding the air vent and the dashboard.

3. This ProClip can be placed anywhere within the width of the airvent.

4. The ProClip is in place.