

Manual, Assembly instruction: Brodit 855646

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the lower edge of the ProClip into the gap between the glove compartment and the dashboard. Hook the upper edge of the ProClip into the gap between the control panel and the surrounding frame.

2. Press down on top of the ProClip so the angled edge hooks properly in place.

3. This ProClip can also be installed onto the left air vent.

4. The ProClip is in place.