

Manual, Assembly instruction: Brodit 855647

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder + equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the bottom angled edge of the ProClip into the gap between the air vent and the surrounding frame.

2. Press downward on the top of the ProClip and insert the top angled edge into the gap between the air vent and the surrounding frame.

3. The ProClip will fit onto both center vents.

4. The ProClip is in place.