

Manual, Assembly instruction: Brodit 855650

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin ends of the enclosed gap openers into the gap between the control panel and the dashboard, to widen the gap.

2. Press the angled edge on the lower part of the ProClip into the gap between the control panel and the dashboard.

3. Press the upper part of the ProClip downward/forwards and hook the angled upper edge into the gap between the gap openers. Pull out the gap openers.

4. The ProClip is in place.