

Manual, Assembly instruction: Brodit 855654

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled upper part of the ProClip into the gap between the air vent and the surrounding frame.

2. Press the lower part of the ProClip upward and forward and hook/snap the lower edge over the frame surrounding the air vent.

3. This ProClip can also be attached onto the left air vent.

4. The ProClip is in place.