

Manual, Assembly instruction: Brodit 855659

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the lower edge of the ProClip into the gap between the panel surrounding the air vent and the control panel.
2. Press forward on the upper part of the ProClip and hook the angled edge behind the dashboard.
3. The ProClip mount is in place.
4. The ProClip mount is in place.