

## Manual, Assembly instruction: Brodit 855661

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.**

1. Press the angled edge on the upper part into the gap between the dashboard and the screen.
2. Pull the ProClip toward you and hook the lower edge into the gap between the dashboard and the frame surrounding the air vent.
3. Press on the ProClip so the adhesive tape attaches properly.
4. The ProClip is in place.