

Manual, Assembly instruction: Brodit 855663

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the panel surrounding the air vent and the control panel,
2. Press the upper part of the ProClip downward/forward and hook the upper edge under the frame surrounding the air vent.
3. This ProClip can also be placed onto the right air vent.
4. The ProClip is in place.