

Manual, Assembly instruction: Brodit 855666

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the lower part of the ProClip over the frame surrounding the air vent.

2. Press the upper part of the ProClip downward/forward and hook the angled edge under the frame surrounding the air vent.

3. This ProClip can also be placed onto the left air vent, and in the center between the air vents.

4. The ProClip is in place.