

Manual, Assembly instruction: Brodit 855669

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Insert the included gap opener into the gap between the silver trim and the air vent, to widen the gap. Hook/hold the ProClip over the dashboard overhang next to the gap opener. Press the lower edge of the ProClip into the gap between the dashboard and the center console. Press upward so the lower angled edge goes all the way into the gap.

2. Press forward on the upper part of the ProClip so the angled edge hooks into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

3. This ProClip can be attached anywhere within the width of the air vents.

4. The ProClip is in place.