

Manual, Assembly instruction: Brodit 855672

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. The vehicle has a cubby just below the center screen. The ProClip will install on the separation lip between the cubby and the climate controls. Hold the ProClip so the longer arm is down. Find the seam just under the cubby: between the soft dash trim and the hard face surrounding the climate controls. Insert the hooked lower edge into the seam. **2.** With the lower lip in place; rotate the Mount upwards. Press the upper lip into the seam between the soft dash trim and the bottom edge of the cubby.

3. This ProClip can be mounted anywhere along the flat edge of the cubby.

4. The ProClip is in place