

Manual, Assembly instruction: Brodit 855675

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap under the frame surrounding the center console, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the lower edge of the ProClip into the gap between the gap openers. Press up on the lower edge of the ProClip so the edge goes all the way into the gap. Pull out the gap openers.

3. Press the gap openers into the gap on top of the dashboard. Press forward on the upper part of the ProClip until you hear/feel the upper edge snaps into place in the gap between the gap openers. Press down on top of the ProClip so the edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.