

Manual, Assembly instruction: Brodit 855682

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the left part of the ProClip around the round frame.
2. Pull the right part of the ProClip away from the dashboard. At the same time, press the right part forward and hook the angled edge between the air vent and the surrounding frame.
3. Press on the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.