

## Manual, Assembly instruction: Brodit 855685

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.**

**1.** Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the upper part of the ProClip into the gap between the soft dashboard ledge and the hard top of the dashboard.

**2.** Pull the lower edge of the ProClip toward you and down. Hook the lower edge under the dashboard ledge.

**3.** The ProClip mount is in place.

**4.** The ProClip mount is in place.