

Manual, Assembly instruction: Brodit 855686

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the upper part of the ProClip into the gap between the panel and the frame surrounding the air vent.

2. Pull the lower part of the ProClip downward and hook the angled lower edge into the gap between the glove compartment and the dashboard.

3. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.