

Manual, Assembly instruction: Brodit 855688

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the upper part of the ProClip into the gap between the dashboard overhang and the panel below it.

2. Press upwards on the bottom part of the ProClip. Hook the lower angled edge over the dashboard rail.

3. This ProClip can also be attached on the right side of the center screen. If installing on the passenger side, the ProClip must be installed within 25 mm / 1" of the screen.

4. The ProClip is in place