

Manual, Assembly instruction: Brodit 855690

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the panel surrounding the air vent and the dashboard.

2. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the air vent and the dashboard, to widen the gap. Pull the upper part of the ProClip upward/forward and hook the angled edge into the gap next to the gap opener. Press on the ProClip so the angled edges go all the way into the gaps. Pull out the gap opener.

3. This ProClip can also be placed onto the right air vent.

4. The ProClip is in place.