

Manual, Assembly instruction: Brodit 855692

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the right edge of the ProClip on the frame surrounding the air vent.

2. Press the left part of the ProClip rightwards and hook the grooved edge onto the frame surrounding the air vent.

3. Press on the ProClip so the adhesive tape attaches.

4. The ProClip is in place.