

Manual, Assembly instruction: Brodit 855693

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap openers into the gap between the soft dashboard surrounding the air vents and the control panel, to widen the gap. Press the lower edge of the ProClip into the gap between the gap openers. Pull out the gap openers.

2. Press the gap openers into the gap between the frame surrounding the screen and the soft dashboard. Pull the upper part of the ProClip upward and forward, and hook the upper edge into the gap between the gap openers. Be careful not to scratch the soft dashboard with the mount. Press down on top of the mount so the edge goes all the way into the gap. Pull out the gap openers.

3. This ProClip can also be placed to the left of the center air vent.

4. The ProClip is in place.