

Manual, Assembly instruction: Brodit 855699

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard placed on the upper right side, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the right part of the ProClip in to the gap below the gap opener.

2. Press the angled edge all the way into the gap. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard placed on the upper left side. Hook the angled left edge of the ProClip into the gap below the gap opener. Press rightward on the left part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.