

Manual, Assembly instruction: Brodit 855700

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. The front lip of the ProClip will be inserted into the defrost vent on the drivers side. The vent is divided into sections by a plastic grill with 18 vertical bars. Count the bars starting from the center of the dashboard and going left. The ProClip will fit on top of number 8. Insert the forward edge of the ProClip into the air vent. The forward edge of the ProClip has a cut out that will fit over grill bar number 8.

2. Press down on the front of the ProClip so it goes all the way down into the vent. Make sure the ProClip is grabbing the dashboard edge and NOT the long vent crossbar. **INSTALLING THE PROCLIP ON THE LONG CROSSBAR COULD DAMAGE YOUR DASH!**

3. Put your fingers behind the mounting plate. Pull the ProClip towards you and down until it clips onto the dashboard trim that overhangs the air vent.

4. The ProClip is in place.