


Manual, Assembly instruction: Brodit 855708

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.

2. Press the upper part of the ProClip downward and forward. Hook the grooved edge on the upper part of the ProClip under the frame surrounding the air vent.

3. This ProClip can also be placed onto the left air vent. A device installed in this position may block the display.

4. The ProClip is in place.