

## Manual, Assembly instruction: Brodit 855712

Center mount



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.**

**1.** Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the hard plastic frame surrounding the screen and the air vent housing, to widen the gap. Press the lower part of the ProClip into the gap between the gap openers. Pull out the gap openers.

**2.** Press the gap openers into the gap between the hard plastic vent frame and the upper dashboard panel. Press forward on the upper part of the ProClip so the upper edge snaps into place in the gap, between the gap openers. Pull out the gap openers.

**3.** This ProClip can be placed anywhere within the width of the air vent.

**4.** The ProClip is in place.