

Manual, Assembly instruction: Brodit 855716

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover on the mount. Place the bottom of the mount on the far right of the flat portion on top of the stereo controls. Gently push the bottom lip into the seam until it catches the back of the stereo housing.
2. Pressing down and in on the top of the mount, place the top of the mount under the infotainment screen
3. Insert the upper lip of the mount into the seam between the vent housing and the infotainment screen base
4. The ProClip is in place.