

Manual, Assembly instruction: Brodit 855718

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the rounded, thicker edge of the enclosed gap opener into the gap between the control panel and the center console, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the angled edge on the lower part of the ProClip under the center console overhang.

3. Press forward on the upper part of the ProClip so the grooved edge snaps into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.