

Manual, Assembly instruction: Brodit 855721

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Place the grooved edge on the lower part of the ProClip over the frame surrounding the air vent, do not press it into the gap yet.
2. Place the grooved edge on the upper part of the ProClip under the frame surrounding the air vent, do not press it into the gap yet.
3. Press forward on the ProClip so the upper and the lower edge go forward simultaneously and snap into place into the gaps.
4. The ProClip is in place. This ProClip can also be placed onto the right air vent in the center console.