

Manual, Assembly instruction: Brodit 855723

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Hook the upper grooved edge of the ProClip under the frame surrounding the air vent.
2. Press the lower part of the ProClip forward and hook the grooved lower edge over the frame surrounding the air vent.
3. Press the ProClip forward so it goes into place properly.
4. The ProClip is in place.