

Manual, Assembly instruction: Brodit 855725

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the upper edge of the right edge of the ProClip into the gap between the housing surrounding the screen and the dashboard panel above the glove box. The ProClip lip will slightly open the gap as it is inserted.

2. Working from the top down, slide the rest of the ProClip edge into the gap. Press to make sure the lip is fully inserted.

3. Hook the left edge of the ProClip over the screen hood. Pull the ProClip forward until it hooks properly in place over the edge of the hood.

4. The ProClip is in place.