

Manual, Assembly instruction: Brodit 855729

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the angled thin edge of the enclosed gap opener into the gap between the frame surrounding the air vent and the trim, to widen the gap.
2. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap surrounding the air vent frame.
3. Press the lower edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.