

Manual, Assembly instruction: Brodit 855731

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console frame and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Place the ProClip over the center console. Press the angled edge on the right part of the ProClip into the gap above the gap opener. Pull out the gap opener.

2. Pull the ProClip toward you and over the center console frame.

3. Press forward on the left side of the ProClip so the angled edge hooks over the center console frame and the adhesive tape attaches properly.

4. The ProClip is in place.