

Manual, Assembly instruction: Brodit 855738

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Place the front and back sections of the mount together. Use the included screws to attach the top plate and secure the sections together. Peel off the adhesive tape cover.

2. Align the mount right of the leather stitching. Press the back edge of the mount in the seam between the leather and window grill.

3. Using both hands, pull forward and down on the front of the mount and place the front lip into the seam between the leather and top dash trim. Firmly press in on the front of the mount to ensure the lip is fully inserted into the seam.

4. The ProClip mount is in place.