

Manual, Assembly instruction: Brodit 855740

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place. It is important to place the ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers. Press the lower edge of the ProClip into the gap between the screen and the trim.
2. Press fownward/forward on the upper part of the ProClip and hook the upper edge under the frame surrounding the air vent.
3. This ProClip can also be placed onto the left air vent.
4. The ProClip is in place.