

Manual, Assembly instruction: Brodit 855741

Angled mount ONLY for models with display.



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the upper part of the ProClip over the frame surrounding the display.

2. Press forward on the lower part of the ProClip so the edge hooks under the frame surrounding the display.

3. Press on the ProClip so the adhesive tapes attach into place properly.

4. The ProClip is in place.