

Manual, Assembly instruction: Brodit 855742

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the lower edge of the ProClip into the gap in the center console sidewall.

2. Flip the ProClip upward/leftward so the lower edge hooks behind the lower section of the center console sidewall.

3. Pull the left part of the ProClip upward and hook the edge over the center console frame.

4. The ProClip is in place.