

Manual, Assembly instruction: Brodit 855745

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the grooved lower edge of the ProClip over the frame surrounding the air vent.
2. Press the upper part of the ProClip downward/foward and hook the upper grooved edge under the frame surrounding the air vent.
3. This ProClip can be attached anywhere within the width of the air vent.
4. The ProClip is in place.