

Manual, Assembly instruction: Brodit 855748

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Insert the included gap openers into the seam between the hard vent plastic and the soft portion of the dash. Make sure to leave enough room between them for the mount to fit.
2. Place the thin upper part of the ProClip into the opening of the hard plastic and soft material.
3. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the gap openers into the seam behind the leather trim next to the engine start button, on either side of the mount. (See photo). Apply even downward pressure that will flex the mount into the soft material and hook it underneath.
4. The ProClip is in place.