

Manual, Assembly instruction: Brodit 855750

Center mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1. The mount comes in two halves that must be fastened together. Making sure the smooth side of the plastic is facing down. The two halves of the mount will be held together by the top plate. Fasten the top plate onto the mount using the included screws.

2. Gently clean the area where the ProClip mount will attach. Remove the cover from the adhesive tape on the mount. Press the thin angled edge on the forward part of the mount into the seam between the top part of the dash and the inner part of the vent.

3. Pull the mount so it flexes towards you hook the thick angled edge on the back side of the mount onto the frame surrounding the center screen.

4. The ProClip is in place.